


Wire & Wireless Integrated Digital Conference System - TOPO



When using the AP Gateway Mode, the "AP Antenna Box" item must be selected in the configure item of "Host" - "system" - "Mode".

Single Wired Mode

Dual-way Loopback Wired Mode (Reserved)

Wireless Mode (with AP)